

INSTRUCTION MANUAL Ver 1.5

1CH IP VIDEO SERVER / MPEG4 Series with Motion Tracking

Firmware Ver. 1.2.1a



① Introduction	3
About This Manual	3
Notes Before Starting	3
Modification and Development	4
Installation	4
② Installation	5
Product Description	5
DDNS Registration	8
Quick Start	9
③ IP Video Server Setup	11
IP Video Server Initial Setup via a Crossover Cable	11
④ Network Setup	14
Guide to Network Setup	14
Case A : Dynamic IP or PPPoE + Personal Router	15
Case B : Static IP + Personal Router	17
Case C : Static IP	19
Case D : Dynamic IP + DSL/Cable Modem	21
Case E : PPPoE + DSL Modem	22
Port Forwarding	23
Starting IVS	24
⑤ Web Viewer	25
Web Viewer Screen	25
How does Motion Tracking work?	29
Create, Save, Load Map	31
Preset	32
Group	33
Viewer Interface	34
⑥ Admin Tool	35
Video Tool	35
Control Tool	37
Motion Detection Tool	38
Motion Tracking Tool	39
TCP/IP Tool	41
DDNS Tool	42
SMTP Tool	43
Date & Time Tool	44
Users Tool	45
Firmware Update Tool	46
Default Set Tool	47
Rebooting Tool	47
⑦ Appendix	48
A : Current TCP/IP setting	48
B : Changing your computer's IP address and subnet mask	49
C : Port Forwarding	50
⑧ FAQ	54
⑨ Specification	58

About This Document

This document is for IP Video Server (IVS) firmware version 1.2.1a or higher and there might be some different contents from IVS firmware version 1.2.1a or lower.

If an administrator has previous knowledge of networking, please follow the Quick Start Guide.

If an administrator is new to networking and has no previous knowledge of the subject, please follow the step-by-step procedures for configuring, installing, and accessing your IP Video Server(IVS).

Please follow the entire walk-through without skipping any steps. The walk-through was designed to teach the typical inexperienced home user how to configure their IVS using the simplest techniques and terminology. Some of these techniques may actually be considered inaccurate, but should suit the needs of most home users. Consult the FAQ and Appendices for further information when required.

After following the walk-through and exhausting all literature, if you can not solve the problems by yourself, please contact our Support Center for technical support.

Notes Before Starting

- This product only works with Microsoft's Internet Explorer in the current versions of Microsoft Windows OS.
- Since ActiveX is to be downloaded from IVS when you firstly connect to it, you must allow ActiveX controls to be downloaded. You can set this allowance in the [Internet Options] in the [Tool] menu of your browser.
- Some pop-up blockers may block legitimate configuration screens, please disable these blockers when configuring the IVS.
- It is noted that some hardware manufacturers include a cable/DSL modem, router/firewall, and Ethernet switch in one device.
- If you have no available ports on your router, you can purchase a 10/100 Ethernet switch to "expand" your Local Area Network
- The crossover cable is not wired as a typical straight-through network cable. This cable (or any crossover) should be used for initial setup of the IVS via a PC/laptop.
- Please temporarily disconnect any proxy servers associated with Internet Explorer while configuring the IP Video Server.

Modification and Development

The Linux-based operating system and flash memory file system enable advanced users and application developers to customize the IP Video Server. An SDK developer kit is available for users to interface ActiveX controls and other applications.

Attempts to modify the IVS will void all warranties and will not be supported by the manufacturer or its seller. Further development tools and documentation for assistance may be accessible in future releases. We strongly recommend that inexperienced users DO NOT modify the firmware of IVS.

The manufacturer or its seller will not be held accountable in a user's attempt to modify the IVS that renders the unit inoperable or otherwise.


Installation

This may be installed as a standalone unit or as a supplement to an existing surveillance system.

Physical connection is utilizing 10/100 base-T Ethernet compatible UTP network cable with RJ-45 connector. Install directly using NTSC or PAL video cameras using BNC connectors.

Product Description

□ Front Panel



- **Power Supply Connector**

Use the power jack to connect your regulated 12Volts DC power adapter.


- **Terminal Block**

This terminal block is used for pan/tilt camera, keyboard and sensor input/output.

- **Network Connector**

This RJ-45 connector is for network connection and designed to operate on 10 or 100 Mbps Ethernet network.

□ Rear Panel




- **Audio In/Out Connect**

Audio IN is monaural 3.5mm mini socket for audio input (to be connected to Amplified Microphone). **Audio OUT** is monaural 3.5mm mini socket for audio output (to be connected amplified speaker).

- **Video In/Out Connect**

Each video input/output is connected using a BNC connector. Physical connections are made using RG-59 coaxial video cable; maximum cable length must be shorter than 800 feet. These provide the connections for virtually any TV systems type; PAL, SECAM or NTSC and devices such as CCTV cameras, Monitors, VCR, DVR, and Camcorders etc.

□ Top View



This red light becomes illuminated when 12V DC power is supplied to the unit. This indicator should always be lit when in use. If it is not lit or flashes when power is supplied, the Video Server is not operating properly.

- **Active LED**

When in use, this Yellow indicator should always be flashing or flickering. During reboots or power cycling, it may take several seconds for the unit to initialize and illuminate the indicator.

- **LINK LED**


This green indicator should be flashing or glowing during normal operation. During a reboot or power cycling, it may take up to 30 seconds to initialize, negotiate your network speed, and begin operation at 10 or 100Mbps. If this light is not lit after 30 seconds of operation, check the network cable to ensure a proper connection. When a proper connection is met, the green indicator should immediately glow.

□ Bottom View

- **Reset Switch**

Return all settings to their factory defaults. Care must be taken since you will lose all data made previously.


Terminal Blocks




Terminal block is used to connect the pan/tilt unit, keyboard and sensor input/output via RS-485.

Pin	Signal	Remarks
1	GND	
2	OUT1	Open Collector
3	COM	Sensor Common
4	SEN1	Sensor GND
5	D+	AUX
6	D-	AUX
7	D+	PTZ
8	D-	PTZ


OUT (Open Collector Out)



IN (Photocoupler)



Crossover Cable



- The crossover cable is not wired as a typical straight-through network cable. This cable (or any crossover) should be used for initial setup of the IVS via a PC/laptop. After initial setup of IVS, use straight-through cable in normal operation.

 **DDNS Registration**

If you have DYNAMIC IP service from your Internet Service Provider (ISP), you can't tell what current IP address of video server is. To solve this problem, you have to register to our DDNS service.

At first, we recommend, you have to check if you are using dynamic addressing. If so, please, register your IP Video Server on our DDNS website before you configure, setup, or install the IVS.

Even though your IP is not dynamic, you will get a benefit if you register to DDNS. In this case, you just remember "alex.net4c.net/gate1" instead of complicated series of number like `http://201.23.4.76:8078`.

For more detail information, please contact our Support Center.

※ To register IVS or IP Camera to DDNS, you should know the Serial No of your IVS. The Serial No can be found in "IP Status" menu of Admin Tool.

※ To use a public DDNS called DtdNS, you can find detail information on how to use this service. (Please, visit its web site : <http://www.dtdns.com>)

Quick Start

Please follow the steps below to complete the initial setup of the IP Video Server (IVS)

- ① Please do not power on the IVS until instructed.
 - ① Temporarily disable any proxy servers configured in Internet Explorer
 - ① If connecting the IVS directly to a modem, power down and reset the modem. Leave the modem powered down until configurations are finalized with the IVS and the IVS has been correctly connected to the modem.
- ① You will need to access a PC/laptop and should configure that PC in order to communicate with the IVS. Record the current TCP/IP properties of that PC (IP address, subnet mask, gateway, DNS, etc)
 - ① If your PC obtains its IP address automatically, then there is no need to record any information.
 - ② Change the IP address of that host PC to 192.168.1.11 and subnet mask to 255.255.255.0 (leave all other entries blank)
 - ③ Connect the IVS to your PC's Ethernet port via the supplied crossover cable (it does not matter what end is used for the PC)
 - ④ Power on the IVS using the supplied power adapter.
 - ⑤ After 1 minute of power, verify a solid POWER indicator, a flashing ACTIVE indicator, and a flashing or solid LINK indicator. After the corresponding indicator lights are properly displayed, open Internet Explorer.
 - ⑥ Type - `http://192.168.1.80` (the default IP of the IVS) into your address bar.
 - ⑦ Default ID/Password to access IVS are both the word: admin
 - ⑧ Familiarize yourself with the Viewer Interface Screen.
 - ⑨ Locate the TCP/IP configuration under Administration Tools. Supply the same ID and Password to enter Administration Tools (admin:admin)
 - ⑩ Under "Network Type" select STATIC. You will only select Dynamic or PPPoE if you are connecting the IVS directly to your cable/DSL/Broadband modem and your Internet Service Provider is supplying you a dynamic or PPPoE address.
 - ① If you have a network with other devices (such as PC/laptop, etc.) or a router, you will NEVER select Dynamic or PPPoE.

- ⑪ Configure the IVS's TCP/IP settings as you would any other PC on your network, providing a proper IP address, subnet mask, default gateway, and DNS server.

① If this is standalone unit with a direct connection to a cable/DSL/Broadband modem then input the addresses you have received from your ISP. If you received no IP address from your ISP, please select Dynamic or PPPoE and choose the proper settings.

- ⑫ The IVS utilizes five TCP ports - a Web Server Port for utilizing Internet Explorer, a Video Server Port, a Control Server Port, Audio ports. A Web Server Port is for utilizing Internet Explorer, a Video Server port is to support the streaming video, and a Control Server Port is to transmit to control command. Also Audio Port are to transmit and to receive Audio data. If this IVS will be directly attached to a cable/DSL/Broadband modem or has been assigned a static IP from your ISP, then leave the default port settings. If you are installing the IVS on a network, you must define a Web Server Port other than 80. The other ports, a Video Server Port, a Control server Port, Audio Ports can remain unchanged.

- ⑬ If the IVS is connected to a network which utilizes a router, you must have Port Forwarding configured on your personal router to forward both the Web Server Port and Video Server Port to the IP address you have assigned the IVS.

- ⑭ After configuring Port Forwarding on your router (if necessary), you may then access your IVS on your local network by opening Internet Explorer and specifying the IP address and Web Server Port that you have assigned to the IVS.

① Examples: <http://192.168.0.200:8888> or <http://24.106.88.123>

① If you left your Web Server Port set to 80, then you don't need to specify the port in the Address Bar when accessing your IVS

- ⑮ Access your IVS via the Internet :

- If you used a static IP address assigned by your ISP

- i) Open Internet Explorer.
- ii) Type the IP of the IVS.
- iii) If you use a router, type the routers' static IP and the web port number of the IVS.

- If you have a dynamic address provided by your ISP

- i) Open Internet Explorer and visit the DDNS website.
- ii) Register the IVS.
- iii) Reboot the IVS.
- iv) Give the DDNS server 2 minutes to locate your IVS's IP information.
- v) Click the refresh button in the Internet Explore.
- vi) After your camera is connected, select your camera.

IP Video Server Initial Setup via a Crossover Cable

This section provides a guide on how to connect the IVS to your PC/laptop for initial setup.

Please follow the instructions in the order they appear, without skipping steps. Do not supply power to the IP Video Server, until instructed.

In order to access the IP Video Server's firmware you will need to connect the Video Server directly to a PC or laptop computer via the supplied crossover cable.

- ① Before you begin, you must determine the current network/INTERNET (TCP/IP) settings on the PC or laptop you plan to setup the IP Video Server. Jot down your entries below for quick reference.

① For information on how to determine your current settings, see Appendix A

Current TCP/IP Settings	
IP Address	
Subnet Mask	
Default Gateway	
Primary DNS Server	
Secondary DNS Server (Option)	

- ② In order for the IP Video Server to communicate with your PC, you have to change your PC's IP address and subnet mask

① We recommend that you change your IP address to 192.168.1.11 and change the subnet mask to 255.255.255.0
Leave all other entries (Default Gateway, DNS Servers, etc.) blank.

① For information on how to change your IP address and subnet mask, see Appendix B


- ③ After you have made the changes to your IP address and subnet mask, you may then attach the IP Video Server to your PC via the supplied crossover cable. Plug-in either end of the crossover cable into the PC's network card and the other end into your IP Video Server.
- ④ After connecting the PC and IP Video Server (IVS) using the crossover cable, power on the IVS by plugging in the power supply shipped with the IVS.
- ⑤ No longer than 1 minute after powering on the IVS, verify that the POWER indicator light is solid, the ACTIVE indicator light is flashing, and the 10M indicator light is flickering or solid. If they are not, please read the FAQ.

⑥ Now you will be able to access the viewer software within the IVS


- ① Open Internet Explorer and type the IP address of 192.168.1.80 (Factory default IP of IVS) into the Address Bar of the web browser (as seen below). Press [Enter].



- ① After pressing [Enter], if a message box as shown below appears, choose "Try Again". The appearance of this message box may vary depending on your operating system.



⑦ Now you will be able to see the login box in the center of web browser to protect unauthorized access.



- ① The 3 authorities are available: Administrator, Operator and Viewer. The authority setup is available in Admin. Tools.

- Viewer Only monitoring is allowed.
- Operator Monitoring, PTZ Control and Digital In/Out Control are allowed.
- Administrator All functions are allowed.

-
- ⑧ The default ID and Password are both the word “admin” (without the “”)
 - ⑨ If at any time you are prompted to download ActiveX controls, you must click ‘Yes’, all content is safe
- ⑩ You will have to click “Yes” button on the dialog box. This allows your video to be displayed in Internet Explorer.



Guide to Network Setup

Please configure the IVS at the location of its installation. You must determine your network scenario in order to configure the IVS with the proper TCP/IP settings. This tutorial will guide you through the process. Before actually configuring the IVS, determine what settings you will apply. Record those settings that you will use to configure your IVS for reference.

When configuring your IVS, treat the IVS as another PC on your network. You will assign it several addresses and other TCP/IP properties to match your current network.

This step-by-step tutorial will teach what IP addresses and network configurations you should assign your IVS based upon your network scenario.

- ① Before you begin, you will need to locate any information and settings that you have received from your Internet Service Provider (ISP). You may need to refer to these IP addresses at a later time during the configuration.

- ① If you were not given any IP addresses or the ISP was responsible for the setup and installation of your Internet connection on your PC or network, then please go to step ②
- ① If you are not using a router on your network, your “Current TCP/IP Settings” (from the previous section) and “Assigned IP Addresses from My ISP” will be exactly the same

Assigned IP Address	
IP Address	
Subnet Mask	
Default Gateway	
Primary DNS Server	
Secondary DNS Server (Option)	

- Static
- Dynamic
- PPPoE

- ② You must determine whether the IP address that you were assigned from the ISP is STATIC, DYNAMIC, or using PPPoE. At this moment, you are only concerned about the ISP. Did they provide you with a STATIC, DYNAMIC, or PPPoE address? If you are unsure, please contact your ISP.
- ③ Configure your IVS’s TCP/IP settings for network connectivity by selecting Administration Tools from the main interface and selecting TCP/IP located on the left of the Administration Tools screen.
- ④ If prompted for an ID and Password, use “admin” for both entries.


The default web port number is 80. If your ISP blocks port 80 you must use a value between 1025-30000. Please consult your ISP and determine if they block TCP port 80.

- ⑤ Depicted below are several basic network scenarios. Determine which scenario describes your network. If your network does not match one of the scenarios below and are unsure how to setup your IVS, please contact your network administrator, then call our Support Center.

①

Dash line box signifies areas of your network that you can't control. Only the ISP has access to these devices.

Case A : Dynamic IP or PPPoE + Personal Router [Most SOHO]



Configure your IVS's TCP/IP properties as follows :

- Network Type
 - STATIC (even though you have Dynamic IP from your ISP, use STATIC on the IVS)

- Internet Address
 - A private IP address such as 192.168.0.200 [Example]


- ① You need to assign the IVS an IP address, just as you would assign a PC.
- ① The IP address you assign must be unique to your network as well as match your network. For information how to choose a unique IP and match your network please read the FAQ.
- ① The IP address you assign the IVS must be a private IP. For information on how to chose a private IP please read the FAQ

- Subnet Mask
 - 255.255.255.0 [Example]

- ① You must use the same subnet mask as the one you noted under “Current TCP/IP Settings”

- ❑ Default Gateway
- 192.168.0.1 [Example]
- ① This IP address must be the IP address of your router (private or LAN side)
- ① Use the same Default Gateway you noted under “Current TCP/IP Settings”
- ❑ Primary DNS Server
- Use the 1st DNS Server from “Assigned IP Address from My ISP”
- ① If you did not receive any IP addresses from your ISP, please contact them and acquire the IP address of their DNS server.
- ❑ DDNS Server
- Use the DDNS server
- ① This is the same site you will register with later to accommodate dynamic IP from your ISP.
- ❑ Web Server Port
- 8888
- ① Do NOT use the default port 80, you must change this number.
- ① You may select any number between 1025 ~ 30000.
- ❑ Control Server Port
- 7777
- ① You may select any number between 1025 ~ 30000.
- ❑ Video Server Port
- 7778
- ① You may select any number between 1025 ~ 30000.
- ❑ Audio Transmit Server Port
- 7779
- ① You may select any number between 1025 ~ 30000.
- ❑ Audio Receive Server Port
- 7780
- ① You may select any number between 1025 ~ 30000.

Case B : Static(Fixed) IP + Personal Router [Efficient]



Configure your IVS's TCP/IP properties as follows :

- Network Type
 - STATIC
- Internet Address
 - A private IP address such as 192.168.0.200 [Example]

- ① You need to assign the IVS an IP address, just as you would assign a PC.
 - ① The IP address you assign must be unique to your network as well as match your network. For information how to choose a unique IP and match your network please read the FAQ.
 - ① The IP address you assign the IVS must be a private IP. For information on how to chose a private IP please read the FAQ
- Subnet Mask
 - 255.255.255.0 [Example]

- ① You must use the same subnet mask as the one you noted under “Current TCP/IP Settings”
- Default Gateway
 - 192.168.0.1 [Example]

- ① This IP address must be the IP address of your router (private or LAN side)
 - ① Use the same Default Gateway you noted under “Current TCP/IP Settings”
- Primary DNS Server
 - Use the 1st DNS Server from “Assigned IP Address from My ISP”

- ① If you did not receive any IP addresses from your ISP, please contact them and acquire the IP address of their DNS server.
- DDNS Server
 - Use the DDNS server

- ① This is the same site you will register with later to accommodate dynamic IP from your ISP.

Web Server Port • 8888

- ① Do NOT use the default port 80, you must change this number.
- ① You may select any number between 1025 ~ 30000.

Control Server Port • 7777

- ① You may select any number between 1025 ~ 30000.

Video Server Port • 7778

- ① You may select any number between 1025 ~ 30000.


Audio Transmit Server Port • 7779

- ① You may select any number between 1025 ~ 30000.

Audio Receive Server Port • 7780

- ① You may select any number between 1025 ~ 30000.

Case C : Static(Fixed) IP [Dedicated line directly to the IP Video Server



Configure your IVS's TCP/IP properties as follows :

- Network Type

 - STATIC
- Internet Address

 - A static IP address received from your ISP, such as 24.107.88.125 [Example]

① You need to assign the IVS an IP address, just as you would assign a PC.
- Subnet Mask

 - Subnet mask assigned from your ISP, such as 255.255.255.240 [Example]
- Default Gateway

 - 24.107.88.113 [Example]

① Use the assigned default gateway from your ISP
- Primary DNS Server

 - Use the 1st DNS Server from “Assigned IP Addresses from My ISP”

① If you did not receive any IP addresses from your ISP, please contact them and acquire the IP address of their DNS server.
- DDNS Server

 - Use the DDNS sever

① This is the same site you will register with later to utilize our DDNS service.
- Web Server Port

 - 80 [default]

① You may select any number between 1025 ~ 30000.
- Control Server Port

 - 7777

① You may select any number between 1025 ~ 30000.

❑ Video Server Port • 7778

① You may select any number between 1025 ~ 30000.


❑ Audio Transmit Server Port • 7779

① You may select any number between 1025 ~ 30000.

❑ Audio Receive Server Port • 7780

① You may select any number between 1025 ~ 30000.

Case D : Dynamic IP + DSL/Cable Modem [Connected directly to the IP Video Server]



Configure your IVS's TCP/IP properties as follows :

Network Type • DYNAMIC

DDNS Server • Use the DDNS server

① This is the same site you will register with later to accommodate dynamic IP from your ISP.

Web Server Port • 80 [default]

① You may select any number between 1025 ~ 30000.

Video Server Port • 7777

① You may select any number between 1025 ~ 30000.

Video Server Port • 7778

① You may select any number between 1025 ~ 30000.

Audio Transmit Server Port • 7779

① You may select any number between 1025 ~ 30000.


Audio Receive Server Port • 7780

① You may select any number between 1025 ~ 30000.

① When connecting the IVS directly to a modem, power down and reset the modem. Leave the modem powered down until configurations are finalized with the IVS and the IVS has been correctly connected to the modem. Then power on the modem, followed by the IVS.



Case E : PPPoE + DSL Modem [Connected directly to the IP Video Server]



Configure your IVS's TCP/IP properties as follows :

- Network Type
 - PPPoE
- User ID
 - Use the User ID or Username you received from your ISP for this direct connection
- User Password
 - Use the Password you received from your ISP for this direct connection
- DDNS Server
 - Use the DDNS server
 - This is the same site you will register with later to utilize our DDNS service
- Web Server Port
 - 80 [default]
 - You may select any number between 1025 ~ 30000.
- Control Server Port
 - 7777
 - You may select any number between 1025 ~ 30000.
- Video Server Port
 - 7778
 - You may select any number between 1025 ~ 30000.
- Audio Transmit Server Port
 - 7779
 - You may select any number between 1025 ~ 30000.
- Audio Receive Server Port
 - 7780
 - You may select any number between 1025 ~ 30000.



Port Forwarding

After entering the correct TCP/IP settings you will be ready for “Port Forwarding” (Cases A, B).

- ❑ Please record the TCP/IP settings of your IVS for future reference. You may need this information to access your IVS and to configure “Port Forwarding”.

IVS TCP/IP Settings	
IP Address	
Subnet Mask	
Default Gateway	
Primary DNS Server	
DDNS Server	
Web Server Port	
Control Server Port	
Video Server Port	
Audio Transmit Server Port	
Audio Receive Server Port	

- ❑ **After clicking “Apply” the system will prompt for a reboot. Please allow the system 30 seconds to reboot and accept the changes. After 30 seconds, close the configuration screen. The view will display “Trying to Reconnect”. If the ACTIVE light on the IVS has gone off and is now back on again flashing, then the IVS has rebooted. After the system reboots completely, remove the power supply from the unit and close Internet Explorer.**
- ❑ Return your PC/Laptop TCP/IP properties to their original settings.
- ❑ Before installing the IVS, you must use “Port Forwarding” on your personal router (Cases A, B). You will need to forward 5 ports:
 - Web Server Port you assigned to the IVS.
 - Control Server Port you assigned to the IVS.
 - Video Server Port you assigned to the IVS.
 - Audio Transmit Server Port you assigned to the IVS.
 - Audio Receive Server Port you assigned to the IVS.

Both of these ports will be forwarded to the IP address you assigned to the IVS.

In the example above, you would forward:

- 8888 → 192.168.0.200 • 7777 → 192.168.0.200
- 7778 → 192.168.0.200 • 7779 → 192.168.0.200 • 7780 → 192.168.0.200

① For information on how to use “Port Forwarding” please read Appendix C

Starting IP Video Server

After correctly forwarding the Web Server Port and the Video Server Port through your router (if applicable), you may then install the IVS in a proper location.

- ① Locate the serial number located on the label attached to the bottom of the IVS, you will need this for DDNS registration.
- ② Connect a device to the IVS (camera, DVR, Pan/Tilt/Zoom, etc.) and supply power to the device.
- ③ Connect the IVS to your router or cable/DSL modem (per your network scenario) via a Cat5/5e UTP Ethernet network cable.
- ④ Supply power to the IVS.
- ⑤ After 30 seconds, verify the IVS indicators:

• POWER	Solid
• ACTIVE	Flashing
• LINK	Flickering/Solid
- ⑥ After configuring Port Forwarding on your router (if necessary), you may then access your IVS on your local network by opening Internet Explorer and specifying the IP address and Web Server Port that you have assigned to the IVS.

① Examples: <http://192.168.0.200:8888> or <http://24.106.88.123>


① if you left your Web Server Port set to 80, then you don't need to specify the port in the Address Bar when accessing the IVS.

- ⑦ Access your IVS via the Internet:
 - If you use Case B or C
 - i) Open Internet Explorer.
 - ii) Type the IP of the IVS.
 - If you use Case A, D, E
 - i) Open Internet Explorer.
 - ii) Visit the DDNS website.
 - iii) Register the IVS.
 - iv) Give the DDNS server 10 minutes (MAX) to locate your IVS's IP information. You may reboot the server to send an immediate request to our DDNS server.
 - v) After your camera is connected, select your camera.

Web Viewer Screen

In this section, the main GUI of the IVS will be explained.

General Tab



- ① Live video Display
- ② OSD - Camera Name / Date / Time
- ③ OSD – In this location, level of user logged will be displayed. For example, ‘G’ means guest level of user.

• G = Guest User : Video monitoring only

- ④ Virtual Joystick Handle for Pan/Tilt control. If you press and drag the handle in the center of circle, the camera will be moved in accordance with your mouse movement. If you release the mouse button, camera will be stopped and the handle will be relocated to the center of the circle. It is noted that the speed will be proportional to the displacement of handle from the center.

- ⑤ Zoom, Focus, and Iris controls for the camera connected to IVS. If you drag the each handle, Zoom, Focus, and Iris are adjusted individually according to your mouse motion.
- ⑥ Tap to switch General or Special function controls. The picture above shows controls when general controls are selected. If you select special tab, you will have more controls such as Map Create, Motion Detection, and Motion Tracking.
- ⑦ Controls for Presets memorized in the PTZ camera. It is noted that some PTZ devices may not support all of these functions and the Preset and Group functions created in the Map(⑬,⑭) are supported by IVS.
- ⑧ Controls for Pattern, Swing and Group functions memorized in the PTZ camera. It is noted that some PTZ devices may not support all of these functions and the Preset and Group functions created in the Map is supported by IVS.
- ⑨ Sensor Alarm Input status and Sensor Alarm Output control.
- ⑩ This button allows transmitting Audio stream from your MIC to IVS.
- ⑪ Volume control for MIC in your computer.
- ⑫ Volume control for speaker out of your computer.
- ⑬ This button allows receiving Audio stream from IVS.
- ⑭ Controls in this area has many functions such as:
 - X2 : 2 times Digital Zoom.
 - OSD : It means "On Screen Display". Click this button to display the captions.
 - Stretch : Stretch will fit the video size to the viewer window regardless of resolution.
 - Capture : Click this button to save video as an image.
 - Admin Tool : Click this button to enter Administration Tools.
 - Connect/Disconnect : Click this button to disconnect or connect from the server.
 - Logout : Click this button to logout.
- ⑮ show the Current Group number. The maximum number of group is 20.
- ⑯ Click to run current group (shown in ⑮).
- ⑰ Display current number of users connected as:
[Current number of users connected / maximum number of users connected].
- ⑱ Show the list of presets selected in the group in ⑮.
- ⑲ Show the information of the preset stored before. The number in the yellow box is the preset number and the number in the orange box means Dwell time. It is noted that the box size means view size of corresponding preset. Accordingly, the smaller box size, the bigger zoom magnification.
- ⑳ This Screen is called map. This map data is normally stored in IVS to share it with all clients. By pressing appropriate button, you may download it from IVS or create to update it.

As explained before, there are three kinds of user authority level i.e. guest, operator and administrator and. It is noted that since the OSD display and Digital Zoom functions do not affect other users view but only affect the current view, these functions can be changed to all user levels. However, since all other functions affect to settings of the video server and accordingly video of all users connected, the user with administrator level can change those functions.

❑ Special Tab




- ① Tab to switch General controls.
- ② Click it to create new map automatically. Before creating new map, please, make sure Camera model in the “Motion Tracking” menu and PTZ Protocol in “Control” menu in the Admin Tool is correctly selected.
- ③ Click it to store map, presets and group data to the IVS.
- ④ Click it to show or hide the preset box and label on the map.
- ⑤ Click it to download the map from IVS.
- ⑥ This button activates or stops motion detection. “Detection Area setting” bellow must be done in advance.
- ⑦ This button activates or stops motion detection target area setup mode

[How To Setup]

- (a) By clicking or dragging of mouse in the main view, you can create or erase the masks on the main view.
- (b) Motion detection is effective in the **Unmask Area**.

(c) Stop and save setting by clicking [Detection Area Setting] button.



- ⑧ This defines the sensitivity of motion detection. Move small circular handle toward the+ direction to increase the sensitivity.
- ⑨ Click it to turn Motion Tracking function on or off.

How does Motion Tracking work?




The “Motion Tracking (MT)” means intelligent moving object following using PTZ camera to get the best incoming information to figure out **behavior of moving target** in the **region of interest**.

Home Position: This is the location where camera waits for moving target object. If object is detected, MT starts from this point. To track object repeatedly, camera will return to Home when target is lost or out of range. A position where MT start button is pressed is set to be the Home position. It is recommended that the Gate or the main Entrance is a good candidate for Home position.

Region of interest: This region is defined by pan and tilt angle in Motion tracking menu in Admin tool. As show in the drawing, it confine the maximum range of MT activities. If MT reaches the limit, camera will return immediately. Otherwise, camera will follow other meaningless objects outside.

MT Procedures:


- (1) Wait at home till a moving target is detected.
The diction condition is defined by user in Motion Tracking menu.
- (2) Track a target by moving pan and tilt.
 - (2-1) Zoom out if target is too big. (Set the size in Motion Tracking Menu.)
 - (2-2) Zoom In if target is too small. (Set the size in Motion Tracking Menu.)
- (3) Zoom 1x if the target is lost. If no more movement are detected, return to home for next target.
- (4) Return to Home position if pan or tilt is out of range.



Priority Rule: Basically, if there are two moving objects crossing, MT will follow bigger sized object.

Rejection of Oscillating Objects: If there is an object oscillating limited distance like swaying tree, flag, MT will consider the distance and count number of oscillation. If the number exceeds the setting value in Motion tracking menu, it will return to home.

MT state diagram: The following state diagram will summarize most of actions explained above.



Create, Save, Load Map

Firstly, make sure Camera Model in “Motion Tracking” menu and PTZ Protocol in “Control” menu of Administration Tools before creating Map. Also, most map related function except “Load” can be operated only by the user who has Administrator authority.

Map	
Create	Save
Load	Show Labels

□ Create Map

- (1) To make the most interested region be located in the center of Map, you have to move the camera to the target scene before new map is created.
- (2) Then, click the [Create] button to make IVS create new map automatically. Please wait for around 5 minutes till the color of Create button returns to grey. If you control something else when map is created, that will disturb creating work. As a result, you will have inaccurate and ugly map.

□ Save Map

If you click [Save] button, the current Map, Preset and Group data will be uploaded to the IVS. By this, you can use stored map data in the future and share it with other Clients.

□ Load Map

If you click [Load] button, the Map, Preset and Group data stored previously will be downloaded from the IVS.

If there is no map data stored in the IVS, you will see only black map in the screen.


□ Show Labels

Show or hide the preset box and label on the map.



Preset

If you draw a box on the map as shown in the picture bellow, the PTZ camera will move and change the zoom ratio to obtain the optimal video matched with the box you just draw.



As shown bellow, if you click the right button of a mouse, you will see the menu item [Save Preset]. If you choose this, you will see a dialog box to specify Preset Number and Dwell Time. Dwell time means how long the camera will stay at corresponding Preset position while performing Group function. Dwell time can be a value 0 to 60 seconds.




If you define a preset, size of view, location, number and dwell time of Preset is denoted on the map as shown in the pictures bellow. Moreover, the detail information of each Preset i.e. Pan / Tilt angle and zoom ratio will be displayed if the mouse approaches to yellow box.



If you click the preset number on yellow box or [Move Preset] menu shown with right click. Camera will move to corresponding preset view.


Group

If you drag a preset number in the yellow box on the map and drop it into the group list box as shown in the picture bellow, corresponding Preset number will be added and registered like “P00” as a member of Group. Maximum 20 presets can be member of one Group. Maximum 20 groups can be register in an IVS.



If you Click [Run Group], camera will move from a preset to other preset listed bellow repeatedly. If it arrive the last one, it will start from the beginning. It is noted that the interval will be determined by dwell time in the orange box and real moving time. To stop group operation, click [Run Group] button again.


To delete a group, select [Clear] menu showing if you click the right button on the Group list.



Viewer Interface

□ Click N Go

By clicking a target in main view, PTZ camera will move to locate the center of view to the target.



□ Box N Go

By drawing a box on the target in main view, PTZ camera will move the camera view to the center of the box and change zoom ratio to match the view size with that of the box surrounding the target.



This section is provided to familiarize the user with the administration tools. Intuitive options are not explained in detail.

All the changes on Administration Tools take effect immediately. These settings will be global, affecting the view of all users currently logged on. However, OSD items selections are effective only after you refresh the viewer windows or restart the internet Explorer.

All settings are always saved in the video server even when you close the viewer program or you turn off the Power of the video server. If you lost your password, you must press the reset button to return all setting to its factory defaults.

Video Tool

Camera

Camera Name :

OSD : Camera Name Date & Time Function Online Users Frame Rate
** These OSD settings are effective after the viewer window is refreshed or reloaded.*

Appearance

Resolution :

Frame Rate : FPS

Camera Flip : Normal Flip

P/T Direction : Normal Reverse

Encoding Parameters

Video Compression : Motion JPEG MPEG-4

Quality & BandWidth

Advanced Setting : Simplified Setting Advanced Setting

Encoding Video Mode : Quality Basis BandWidth Basis

Quality :

Bit Rate :

- Camera Name For easy identify the cameras, you can freely assign a name to the device or camera connected to the IVS. This will change the camera name on OSD. (Maximum 7 characters available)
- OSD Select OSD items displayed on the screen. This will effect only after refresh site or restart your internet explorer.
- Resolution Select the resolution (or video size) of the viewer screen.

- Frame Rate** Maximum frame rate of video to limit the traffic occupied.
- Camera Flip** Flip the video orientation. (i.e. Turn the video upside down.)
- P/T Direction** Define the direction of Pan/Tilt motion.
- Video Compression** Choose the video compression method form Motion JPEG and MPEG-4 formats.
- Simplified Setting and Advanced Setting** In fact, these two has same concepts. However, the **Simplified Setting** is described in terms of simple and easy expressions to help nonprofessional users. If you are professional and want to set delicately, choose **Advanced Setting**.
- Encoding Video Mode** In **Quality Basis mode**, you can select video encoding and streaming in the viewpoint of video quality rather than bandwidth occupied. In this case, Bandwidth can be traded off to meet your video quality requirement under some network environments. (This mode is same as VBR mode in Advanced setting)
In **Bandwidth Basis mode**, you can select video encoding and streaming in the viewpoint of Bandwidth rather than video quality displayed. In this case, quality can be traded off to meet your bandwidth requirement under some network environments. (This mode is same as CBR mode in Advanced setting)
- Quality** This setting is available only Quality Basis mode. The quality level can be selected from 5 grades “A”, “AA”, “AAA”, “AAAA”, “AAAAA”. It is noted that if you select Advanced Setting mode, you can define more grades (1 ~ 31).
- Bit Rate** This setting is available only Bandwidth Basis mode. The bandwidth can be select one of 10 values between 30Kbps to 5100Kbps. It is noted that you can select from more than 170 steps in Advanced Setting.

Control Tool

Serial Port Protocol

Com1 Devices : [PTZ Control]

Com2 Devices : [Auxiliary Device]

Com1 Port Setup

PTZ Camera ID : [0 ~ 255]

Baud Rate : Data Bit :

Stop Bit : Parity :

Use Advanced Communication Setting

Camera Pan Direction

Direction : CCW CW

- Com1 Devices For PTZ devices only. Select the PTZ control protocol.

- Com2 Devices For Digital I/O module and Keyboard. Select the module type.

- PTZ Camera ID For PTZ Device Address Setup. 0 ~ 255 are available.

- Baudrate, Data Bit, Stop Bit, Parity Bit This setup is only for the non-standard protocols. Sometimes, PTZ protocol of some manufacturers requires communication settings different from those of the standard. To meet these special settings, click the check box of “**Use Advanced Communication Setting**” bellow.

- Use Advanced Communication Setting Used to adjust Baud Rate, Data Bit, Stop Bit, Parity Bit of the selected protocol. Do not use if the select protocol is standard.

- Camera Pan Direction When the direction of camera pan is increasing clockwise, choose “CW”. Other wise, choose “CCW”.

Motion Detection Tool

Detection Action

Alert Sound

Out 1 Out 2 Out 3 Out 4

- Detection Action** Set up the reaction of IVS when motion detected.
- Alert Sound : Audio Out through the Audio out jack of IVS.
- Out 1 ~ 4 : Select output relay numbers in the Sensor Alarm I/O module connected with IVS.

Motion Tracking Tool

Camera & Display	
Camera Model	SAMSUNG 10X (Digital 10X) ▾
Tracking Sensitivity & Range	
Tracking Sensitivity	4 ▾ [0 ~ 7, Default : 3]
Tracking Range	<input checked="" type="checkbox"/> ALL PAN 0 ~ 359 TILT 0 ~ 89
No Motion Timeout (% with respect to Screen size)	
No Motion Wait (⇒)	30 Sec. [0 ~ 255, Default : 15] Then 1X Zoom Out
1X Zoom Wait (⇒)	15 Sec. [0 ~ 255, Default : 30] Then return to Home
Escape from Oscillating Environment	
Oscillation Magnitude (≤)	25 % [0 ~ 100, Default : 25] And,
Oscillation Count (⇒)	50 [0 ~ 100, Default : 50] Then return to Home
Object	
Object Size (≤)	50 % [0 ~ 100, Default : 50] Then start to track
Object Size (≤)	25 % [0 ~ 100, Default : 25] Then Zoom In
Object Size (≥)	50 % [0 ~ 100, Default : 50] Then Zoom Out

- Camera Select model of Zoom Camera Module.
- Tracking Sensitivity Select the sensitivity 0~7 for target's movement during Motion Tracking. The bigger number, the more sensitive.
- Tracking Range Define the coverage of "Motion Tracking operation". If you want to apply motion tracking for all area, check the box before ALL. Otherwise, uncheck the box and specify the range of both Pan and tilt angles in degree. If the center of camera is out of effective range, the camera will return to its home position. This Range setting is very useful to exclude unwanted objects which is located some known area. For example, if your operating area has continuous moving objects such as liver, side walk or Free way which is not important for your application, you can assign effective area of motion tracking by setting both ranges of pan and tilt angle to exclude those area.
- No Motion Wait The time out of waiting during motion tacking state. If the moving object is occluded or out of view, camera will wait for a while. Otherwise, camera will be trapped forever. So, this value means timeout of waiting time. After this amount of wait time, camera will automatically zoom out to 1x to search the object lost.

- ❑ 1x Zoom Wait The time out of waiting after 1x zoom state. If camera loses a target object, it will automatically zoom out to 1x to search the object lost. If there is no moving object for a while, the camera will return to Home Position where “Motion Tracking” starts.
- ❑ Escape from Oscillating Environment If there are oscillating object which is swaying left / right or up/down with limited amplitude (like swaying tree), camera will be trapped to this object forever since camera can not tell whether it is real moving object or not. To escape from this kind of trap, we can assign escape conditions using two parameters i.e. Oscillation magnitude and count. If this condition is reached, the camera will return to Home to find out new moving object.
Oscillation magnitude means percentage size of oscillation magnitude with respect to camera view size (this size is depending on zoom ratio). **Oscillation count** represents number of oscillation. To help understanding, let's assume oscillation magnitude is 10% and count is 50. If there is a leave swaying by wind continuously and its amplitude of oscillation is roughly under 10% with respect to view size of the camera, IVS will count the number of oscillation till it reaches 50. Then, IVS will ignore this object motion and make camera return to Home.
- ❑ Object Size There are 3 kinds of object size to be defined. To set up this easily, you must understand three characteristic of Motion tracking feature.
1. If size of moving object is too big, IVS will ignore this object since it is likely to be noise, rain or Camera motion itself. In other words, IVS will track the object smaller than size in the first box.
 2. If size of moving object is small, IVS will send a command to increase the size by zooming in a little bit to see detail. In other words, IVS will make camera zoom in if the object is smaller than size in the second box.
 3. If size of moving object is big, IVS will send a command to reduce the size by zooming out a little bit not to lose the target. In other words, IVS will make camera zoom out if the object is bigger than size in the third box.

TCP/IP Tool

Network Type	
<input checked="" type="radio"/>	Static
<input type="radio"/>	Dynamic
<input type="radio"/>	PPPoE

IP Setup	
IP Address :	<input type="text" value="192.168.1.80"/>
Subnet Mask :	<input type="text" value="255.255.255.0"/>
Default Gateway :	<input type="text" value="192.168.1.1"/>
Preferred DNS Server :	<input type="text" value="168.126.63.1"/>
Web Server Port :	<input type="text" value="80"/> [Default : 80 Available Range : 1025 ~ 30000]
Control Server Port :	<input type="text" value="7777"/> [Default : 7777 Available Range : 1025 ~ 30000]
Video Server Port :	<input type="text" value="7778"/> [Default : 7778 Available Range : 1025 ~ 30000]
Audio Transmit Server Port :	<input type="text" value="7779"/> [Default : 7779 Available Range : 1025 ~ 30000]
Audio Receive Server Port :	<input type="text" value="7780"/> [Default : 7780 Available Range : 1025 ~ 30000]

- | | |
|---|--|
| <input type="checkbox"/> Network Type | Select a Static or Dynamic address scheme that is used by the Internet Service Provider (not the addressing scheme used by a personal router). |
| <input type="checkbox"/> Internet Address | Input a value to assign an IP address to the IVS. |
| <input type="checkbox"/> Subnet Mask | Input a value to assign a subnet mask to the IVS. |
| <input type="checkbox"/> Default Gateway | Input the IP address of the default gateway. |
| <input type="checkbox"/> Primary DNS Server | Input the IP address of an ISP's DNS server. |
| <input type="checkbox"/> Web Server Port | Assign a TCP port number to assign a Web Interface port number to the IVS. This port is used for transmitting ActiveX program to web browser based viewer. |
| <input type="checkbox"/> Video Server Port | Assign a TCP port number to assign a Video Server port number to the IVS. |
| <input type="checkbox"/> Control Server Port | Assign a port number for control server. This port is used for camera control. |
| <input type="checkbox"/> Audio Transmit Server Port | Assign Audio data send server port number. |
| <input type="checkbox"/> Audio Receive Server Port | Assign Audio data receive server port number. |

DDNS Tool

DDNS Setup

Use DDNS

Primary DDNS Address :

Secondary DDNS Provider :

Host Name :

User Name :

User Password :

- Use DDNS If you check this box, **DDNS** updating is enabled. (primary and secondary)
- Primary DDNS Address Assign DDNS address. (default. **www.net4c.net**)
- Secondary DDNS Provider Select DDNS Provider. Currently, **DtDNS** is available.
- Host Name Type the host name registered in DDNS service.
(i.e. Host name in **DtDNS**)
- User Name Type user name used for DDNS service.
(i.e. User Name(ID) registered in **DtDNS**)
- User Password Type the password used for DDNS service.
(i.e. Password registered in **DtDNS**)

SMTP Tool

This function is used to email the specified email recipient and notify that individual of the IP address / web port number used to access the IVS. This email function is only activates on power-on reset time of IVS.

E.Mail Server

SMTP Server :

User Name :

User Password :

Setting : Send E-Mail box SMTP Requires authentication

E.Mail Address

From :

To :

- SMTP Server Enter an SMTP server to send email.
- User Name Input user name used for SMTP authentication to access the mail server.
- User Password Input the password used for SMTP authentication to access the mail server.
- Send E-Mail box If this check box is set to on, email function is enabled.
- SMTP requires auth. Check this box if the mail server requires SMTP authentication.
- From Input the email address of sender. The email address should be admitted to the SMPT sever.
- To Input the email address of receiver.

Date & Time Tool

The screenshot displays a web-based configuration interface for camera date and time. It is divided into two main sections: 'Current camera date & time' and 'New camera date & time'. The 'Current' section shows the date as 11/01/2007 and the time as 14:41:52. The 'New' section offers three synchronization methods: 'Synchronize with my computer time' (with date 11/01/2007 and time 14:42:03), 'Set up manually' (with input fields for date in mm/dd/yyyy format and time in hh:mm:ss format), and 'Synchronize with time server' (which is selected). The 'Synchronize with time server' section includes a dropdown menu for 'Time Zone' set to '(GMT+09:00) Seoul, Tokyo' and a text input field for 'Time Server' set to 'time.bora.net'.

- Current Date/Time** It shows the current Date/Time setting of IVS.
- New Date/Time** Select the method of Date/Time setting. Date/Time can be set by local computer or time server or manual.

Users Tool

The screenshot shows the 'Users Tool' interface. It is divided into two main sections: 'System Manger' and 'General Users'.

System Manger: A table with columns: ID, Password, Verify, and Auto Login. The first row contains 'master', '*****', '*****', and an unchecked checkbox.

General Users: A table with columns: NO, ID, Authority, and Auto Login. It contains two rows:

NO	ID	Authority	Auto Login
1	guest	Viewer	
2	admin	Operator	U

Below the 'General Users' table is a form with columns: ID, Password, Verify, Authority (with a dropdown menu), and Auto Login (with a checkbox). At the bottom right are buttons for 'Add', 'Edit', 'Delete', and 'Clear'.

- ❑ **System Manager** Specify an ID and Password for the System Administrator of the IVS. The System Administrator will have all rights and privileges to manage the system.

① After changing Administrator's ID and Password, IVS should be booted to apply new ID and Password.
- ❑ **General Manager** Give access privileges up to 40 separate user accounts.

① Only 40 users may be logged on simultaneously, regardless of what user identities are logged on.
- ❑ **To add a user** Input an ID and Password, verify Password, select Authority, click ADD.
- ❑ **To edit a user** Select the user from the list of users, make necessary changes, click EDIT.
- ❑ **To delete a user** Select the user from the list of users, click DELETE.
- ❑ **Operator Authority** This privilege gives the user rights to operate the PTZ controls.
- ❑ **Viewer Authority** This privilege gives the user rights to operate only the icons associated with digital 2× zoom, stretch, OSD, and video capture. These options only affect that current user. The changes made there will have no effect on the other users logged on.
- ❑ **Auto Login** Only one user/administrator may have Auto Login enabled. When the video server is accessed, it will bypass the login screen and logon automatically.

Firmware Update Tool

Version

Firmware Version : SD-1.2.0-E

Notice

1. Closing browser or Clicking menu bars during update may cause critical problems.
2. Network Camera reboots automatically after update.

Update Status

Firmware Filename :

- ❑ Version Shows the current firmware version.
 - ❑ How to upgrade Click [Browse...] button and select the latest version of the firmware. Its file name should be **.bin.
- Click [Update Start] button. It will start upgrading its firmware. IVS will re-boot automatically as soon as it finish the upgrade process.

- ① After upgrade, its system configuration should be set to factory default.
- ① Connect IVS to a computer directly with a crossover Ethernet cable. Do not use internet to upgrade. There may be unexpected disconnection on internet during upgrade and it may cause fatal system damage.
- ① Do not close browser or click menu during update. It may cause fatal system damage.

Default Set Tool

Reset its system configuration to the factory defaults.

Note) After initializing, all information should be deleted. Please re-consider before initializing.




Rebooting Tool

Re-boots IVS.



A : Current TCP/IP Settings


❑ For Windows 98 / ME Users



- Note the settings under the IP Address, DNS Configuration, and Gateway tabs

① If your IP settings are obtained automatically, you could use the MS-DOS prompt (or Command Prompt) to determine your IP address. For information on how to do this, please read the FAQ.

❑ For Windows 2000 or Windows XP




- Under the “General” tab of the TCP/IP Properties you will see your IP address information.

① If your IP settings are obtained automatically, you could use the MS-DOS prompt (or Command Prompt) to determine your IP address. For information on how to do this, please read the FAQ.


B : Changing your computer's IP address and subnet mask

❑ For Windows 98 / ME Users



- Select 'Use the following IP address' and change the IP address and Subnet Mask.

❑ For Windows 2000 or Windows XP



- Select 'Use the following IP address'

C : Port Forwarding


After assigning the IVS a web server port and video server port you must use Port Forwarding (for cases A, B)

Please consult your router's user guide on how to correctly configure Port Forwarding.

For your convenience, we have provided two example configurations.

❑ For D-Link DI-604 broadband routers:

- ① Open a web browser and type `http://192.168.0.1` into your Address bar. (the default IP address to access the router)
- ② You will have to supply your User Name and Password to log onto the router. Default from factory. (User Name: admin Password: [leave blank])
- ③ Select the advance tab and click "Virtual Server" menu.



- ④ Click "Apply" button after inputting proper values. The example is as below

- Enabled / Disabled Select “Enabled”.
- Name Input IVS name.
- Private IP Input IVS address.
- Protocol Type Select “TCP” .
- Private Port / Public Port Input IVS Web Server Port.
- Schedule Select “Always”


- ⑤ If 'Setting Saved' shows, click [Continue] button.
- ⑥ With the same method as above, add Video Server Port and 2 Audio Ports.
- ⑦ The Web Server Port, Video Server Port and 2 Audio Ports shows in "Virtual Server List" as below.

Virtual Servers List


	Name	Private IP	Protocol	Schedule	
<input checked="" type="checkbox"/>	NVS_2	192.168.0.80	TCP 8080/8080	always	 
<input checked="" type="checkbox"/>	NVS_2	192.168.0.80	TCP 7777/7777	always	 
<input checked="" type="checkbox"/>	NVS_2	192.168.0.80	TCP 7778/7778	always	 
<input checked="" type="checkbox"/>	NVS_2	192.168.0.80	TCP 7779/7779	always	 
<input checked="" type="checkbox"/>	NVS_2	192.168.0.80	TCP 7780/7780	always	 

❑ **For Linksys BEFSR41 Cable/DSL routers:**

- ① Open a web browser and type `http://192.168.1.1` into your Address bar (the default IP address to access the router)
- ② You will have to supply your User Name and Password to log onto the router. Default from factory (User Name:[leave blank] Password: admin)
- ③ Select Applications & Gaming from the menu bar.



- ④ Input port numbers in "Port Range" as below and click [Save Setting] button. Both of Web Server Port and Video Server Port should be added. The example is as below.



- Application Input IVS name.
- Start / End Input IVS Web Server Port and Video Server Port.
Start should be same as End.
Both of Web Server Port and Video Server Port should be added.
- Protocol Select "TCP" in Protocol option.
- IP Address Input IVS IP Address.
- Enabled Check the square.

❑ For Netgear RP614 routers

- ① Input <http://192.168.0.1> in address bar of web browser. <http://192.168.0.1> is the default IP address.
- ② If it asks ID and password, input admin as ID and password as password.
- ③ Click "Port Forwarding" in "Advanced".
- ④ Click "Add Custom Service" button in Port Forwarding page.

Port Forwarding

Service Name: SERVICES Server IP Address: 192 . 168 . 0 . [] Add

#	Enable	Service Name	Start Port	End Port	Server IP Address
	<input type="checkbox"/>				

Add Custom Service Edit Service Delete Service

Apply Cancel

- ⑤ Input proper values in "Ports - Custom Services" page as below.

Ports - Custom Services

Enable

Service Name: []

Starting Port: [] (1~65535)

Ending Port: [] (1~65535)

Server IP Address: 192 . 168 . 0 . []

Add Cancel

- Enable Check it.
- Service Name Input IVS name.
- Starting/Ending Port Input IVS Web Server port. Starting Port should be same as Ending Port.
- Server IP Address Input IVS IP Address.

- ⑥ Click "Add" button.
- ⑦ With the same method as above, add Video Server Port.
- ⑧ Click "Apply" button to finish Port Forwarding.

❑ I can't connect!!

In the case of a connection failure.

Modem Reboot > Modem Reboot Finished > Router Reboot > Router Reboot Finished > IVS Reboot > IVS Reboot Finish > Verify DDNS and IVS connection, if applicable.

❑ How do I choose a unique IP address that matches my network?

For your home or small office, ensure that all devices on your network are running. PING an IP address that you plan to assign to the IVS. If you receive a "Request timed out", then you may use that IP address. To ensure the IP address that you will assign the IVS matches your network, review your "Current TCP/IP Settings" that you had recorded earlier. See some examples below:

- If your "IP Address" entry in "Current TCP/IP Settings" was 192.168.0.y, and your "Subnet Mask" was 255.255.255.0 then use 192.168.0.x for your IVS's IP Address ("x" meaning any number between 2-254 that you wish, as long as it passes the "PING" test).
- If your "IP Address" entry is not a 192.168.z.y address with a "Subnet Mask" of 255.255.255.0 then please contact our Support Center.
- If your "IP Address" entry is not a 192.168.z.y address, please contact our Support Center.

❑ How do I open an MS-DOS or Command Prompt?

- Windows 98 / ME Users : Start → Programs → Accessories → MS-DOS prompt
- Windows 2000 / XP Users : Start → (All) Programs → Accessories → Command Prompt

❑ How do I "PING" an IP address?

- ① Open an MS-DOS (or Command) prompt
- ② At the prompt type - "ping xxx.xxx.xxx.xxx" (without the quotes and replace the "x"s with an IP address)
- ③ Press Enter

❑ How do I enable or check ActiveX on my browser

Open Internet Explorer → Tools on the menu bar → Internet Options → Security Tab → Custom Level → Scroll down and verify that you are prompted or have enabled ActiveX controls and plug-ins to be downloaded and executed. → click OK → restart browser

❑ How do I find out my IP address information if my settings were automatically detected?

- Windows 98 / ME Users
 - ① Open an MS-DOS Prompt
 - ② At the prompt type: “winipcfg” (without the quotation marks)
 - ③ Use the drop down list to select your 10/100 Ethernet Adapter (not a PPP adapter)
 - ④ Now you will see your IP Address, Subnet Mask, and Default Gateway information
 - ⑤ For DNS information contact your Internet Service Provider
- Windows 2000 / XP Users
 - ① Open a Command Prompt
 - ② At the prompt type - “ipconfig /all” (without the quotes)
 - ③ Near the end of the information supplied, should be your current IP address, subnet mask, default gateway and DNS servers

❑ How do I choose a private IP address:

Assign your IVS a private IP address that matches your current network. Below lists the ranges for private addresses:

- Private Class A address space : 192.168.0.0 - 192.168.255.255
- Private Class B address space : 172.16.0.0 - 172.31.255.255
- Private Class C address space : 10.0.0.0 - 10.255.255.255

❑ My POWER light is not on?

Power is not being supplied to the unit. Please use the power supply shipped with the unit and verify that a power source is active from the attached power outlet used to connect the adapter. You can test this by plugging in any other electrical device and verify its operation. After using the power supply shipped with the product, checking the power source, and reinserting the power connector into the IVS, please call our Support Center. The power supply may be defective.

❑ My ACTIVE light is not flashing?

Verify the power supply to the unit. Power off the unit and back on again, wait 1 minute, if the ACTIVE light still does not begin to flash, you will have to set the unit to its factory default (THIS WILL DELETE ANY CONFIGURATION AND SET THE UNIT TO THE FACTORY DEFAULTS). Power on the unit and insert the end of a paper clip into the small recessed opening on the back of the unit. Use the clip to press the button located within that opening.

❑ **My LINK light is not flashing or solid?**

Verify the cable connection. 99% of the time the cable's connection to the unit is causing this problem. Try using a different network cable or crossover cable (for PC connection only). Try reinserting the cable, if this still doesn't solve the problem call our Support Center.

❑ **I want to prevent users from viewing my camera.**

- ① Go into Administration Tools of the IVS.
- ② Click on Users
- ③ Delete the user or all users by deleting the ID and password associated with that user.

❑ **Can I record the video?**

Yes you can record, but you will need to purchase a separate software program to allow PC-based recording. This software is available by contacting your distributor or our Customer Service Center. The software named "I-PRO" will connect up to 16 separate 1-channel video servers for remote viewing, remote controlling, and remote recording without the loss of quality or size (up to 640×480 resolution).

❑ **I can access the video server on my LAN, but not from the Internet.**

Verify that your router (if applicable) has port forwarding properly configured. If accessing from our DDNS service, verify correct serial number. Firewall issues may prevent user access.

❑ **How do I reset the unit to factory defaults?**

On the underside of the unit you will find a recessed opening located near the top-left side of the label. Power ON the unit and use a paper clip to push the reset button within that opening. You should then see the ACTIVE light turn off and after a few seconds the ACTIVE light will begin to flash, signifying a successful reboot. If the ACTIVE light does not turn off after depressing the reset button, please try holding the button in for a few seconds and releasing. **YOU WILL LOSE ALL DATA THAT HAD BEEN ENTERED PREVIOUSLY AND THE IVS WILL BE SET TO ITS FACTORY RESETS.**

❑ **Can I use the IP Video Server on my dial-up Internet connection?**

No, we recommend a high-speed broadband connection of at least 128Kb/sec.

❑ **I'm accessing my video server remotely over the Internet and the video stream is choppy, is this normal?**

Yes. The frames per second received remotely are determined by your bandwidth capabilities both at your site where the IVS is installed and your remote location. The lower of the two sites will determine how fast your video stream is received. It is recommended to have at least a 256Kb/sec upstream connection from the site where the IVS is installed. Lower speeds will operate properly, but provide poor remote performance. The Faster the Internet connection at both ends, the faster the video stream.

❑ **Can I view multiple cameras at once?**

Currently the IVS supports 1 channel of video input. Typically, one camera per IP Video Server.

You can view multiple cameras only if the IVS is connected to another device supporting multiple cameras (DVR, multiplexer, etc.) or if you purchase the I-PRO II software which will connect up to 16 separate IVS, each connected to their own camera or device.

Specifications

Model		IP Video Server
Hardware	CPU	32Bit RISC Processor
	OS	Embedded Linux
Viewer		Web Browser based Monitoring
Network	Protocol	TCP/IP
	Interface	10/100 base-T Ethernet (RJ-45)
Compression	Algorithm	MPEG-4
	Rate	NTSC : 720 x 480 @ 30 Hz PAL : 720 x 576 @ 25 Hz
Video	Input	1CH. NTSC/PAL
	Output	1CH. NTSC/PAL
	Size	720 x 480, 352 x 240
	Frame Rate	30 frame/sec (720 x 480)
Audio	Input / Output	Bidirectional
	Compression	ADPCM
Pan/Tilt Control	Communication	RS-485
	Protocol	Pelco-D etc.
Sensor I/O (option)	Communication	RS-485
	I/O	8 Inputs / 4 Outputs
Power		DC12V / 600mA
Operating Temperature		0°C ~ 40°C
Dimension		110(W) × 110(H) × 27(L) mm including bracket
Weight		Approx. 150g

* Specification & design are subject to change without notice

- Web Browser Viewer



- I-PRO II Multi-Viewer

