



# PTZ WIRING SETTING

The POWER and VIDEO works same as regular camera.




## PTZ to STANDALONE DVR

For this example we are using HT-Series



**PTZ to PC DVR (9000 SERIES)**



**PTZ to KEYBOARD to STANDALONE DVR**

